



- 1) Grid Fixing Head Pulley
- 2) Grid Fixing Drop Pulleys
- 3) Flyrail Cleat
- 4) Hand Rope
- 5) Top Batton Clip

Scenery hand rope sets provide a quick and simple means of raising and lowering light scenery and masking borders, which makes it possible to change scenes fast and efficiently.

This is why our hand rope sets are installed in almost every theatre and Community Hall throughout the country.

We recommend the installation of a double cleat rail in order to provide a "lowering dead" as well as a top cleat for a "tie off", and also the use of the grid pulley for timber grids as illustrated. Other pulley arrangements are possible however.

